



NIMA Civil and Commercial Applications Project: Image Interpretability and Feature Extraction of Ikonos Imagery Products

UNCLASSIFIED

Braxton Baldrige

703-262-4345

baldrdb@nima.mil



Overview

- CCAP
- Scope of Ikonos Evaluation
- Imagery Parameters
- Products Ordered
- Imagery Interpretability Assessment
- Feature Extraction Assessment
- Imagery Processing
- Evaluation Procedure
- Analysis & Reporting
- Summary



Civil and Commercial Applications Project (CCAP)

- CCAP is NIMA's resource for evaluating the utility of emerging civil and commercial satellite sensors
- Joint effort between the Commercial Imagery Program (CIP) and the Imagery Assessments Branch (ATSAI)
- CCAP is teamed with NASA and the USGS as a member of the Joint Agency Commercial Imagery Evaluation (JACIE)
- Completed CCAP evaluations:
 - Canadian Radarsat
 - SPIN-2




Scope of Ikonos Evaluation

- Evaluating Ikonos pan, MSI, and pan-sharpened products for:
 - Image Interpretability (II) for intelligence, military, and civil applications (pan, MSI, pan-sharpened)
 - Feature Extraction (FE) for mapping applications (pan, MSI, pan-sharpened)
 - Radiometric Accuracy & Precision (MSI only)
- Evaluating orthorectified and stereo products for geospositional accuracy



Ikonos Evaluation





Imagery Parameters

- 32 scenes acquired for II and FE evaluation
- 13 scenes acquired for geo-positional evaluation
- 2 scenes tasked for radiometric evaluation
- Pan and MSI imagery of four climate regions:
 - Arid
 - Tropical
 - Temperate North
 - Temperate South



Ikonos Products Ordered (II & FE, Radiometric Accuracy)

- Level 1 (radiometrically corrected only), TIFF formatted Panchromatic
 - 11k x 11k image size
- Level 1 TIFF MSI
 - 11k x 11k image size
 - **B, G, R & NIR bands**
- Level 1 TIFF Pan-sharpened
 - 11k x 11k image size
 - **B, G, R & NIR bands**



Ikonos Products Ordered (Geo-positional Accuracy)

- Level 2 (radiometrically and geometrically corrected),
GeoTIFF formatted orthorectified (Pro-Ortho)
 - **Panchromatic**
 - **5k x 5k image size**
 - **WGS84 UTM**
 - **10.2 meter accuracy (CE 90)**
- Level 2 GeoTIFF orthorectified (Precision Ortho)
 - **Panchromatic**
 - **5k x 5k image size**
 - **WGS84 UTM**
 - **4 meter accuracy (CE 90)**
- Level 2 NITF Stereo Pairs
 - **Panchromatic**
 - **9k x 9k image size**



Imagery Interpretability Assessment

- Provide NIMA customers a general idea of what intelligence tasks can be accomplished with Ikonos pan and MSI data
 - Use the National Image Interpretability Rating Scale (NIIRS) and Multispectral (MS) IIRS to establish a mean rating scale value for the imagery sample:
 - NIIRS: Graduated 10 point scale designed to quantify and communicate the potential interpretability of panchromatic imagery
 - MS IIRS: Graduated 7 point scale designed to quantify and communicate the potential interpretability of MSI
 - Quantify the information content of the imagery as characterized by task satisfaction of Essential Elements of Information (EEI):
 - Based on image observables
 - Address specific intelligence tasks




NIIRS Rating



Copyright 2000 Space Imaging, Inc.


0 1.0 2.0 3.0 4.0 5.0 6.0 7.0 8.0 9.0



“What’s the NIIRS rating
for this image?”



EEI Confidence



“What’s your confidence in your ability to detect large bombers?”

Copyright 2000 Space Imaging, Inc.

March 20th, 2001

High Spatial Resolution Commercial Imagery Workshop

UNCLASSIFIED




MS IIRS Rating



Copyright 2000 Space Imaging, Inc.




0 1.0 2.0 3.0 4.0 5.0 6.0 7.0



“What’s the MS IIRS rating
for this image?”



MS EEI Confidence



“What’s your confidence in your ability to identify wetland vegetation type (e.g., mangrove, grasses, etc)”

Copyright 2000 Space Imaging, Inc.

March 20th, 2001

High Spatial Resolution Commercial Imagery Workshop

UNCLASSIFIED




Feature Extraction Assessment

- Provide NIMA customers a general idea of the utility of Ikonos imagery products for mapping applications:
 - Pan, MSI, and Pan-sharpened products
 - True color and false color composites displayed side-by-side
- Confidence ratings (0-100) solicited on analyst's ability to extract a given feature
- Once extracted, analyst asked attribute questions about the given feature (multiple choice)



Feature Extraction Confidence



What's your confidence in your ability to extract a railroad track from this image?

Copyright 2000 Space Imaging, Inc.



Attribute Response



What is the railroad track power source?

- A) Overhead electric**
- B) Electrified rail**
- C) Unknown**

Copyright 2000 Space Imaging, Inc.



Imagery Processing

- Imagery resized for evaluation display:
 - 2k x 2k pixel-sized chips for panchromatic and pan-sharpened
 - 512 x 512 pixel-sized chips for MSI
- 0.5% linear stretch applied universally to imagery
- Each chip set rotated to the appropriate cardinal direction to best align obliquity to the top of the image display



Evaluation Procedure

- Imagery evaluated by ATSAI and community Image Analysts (IAs) and Geospatial Analysts/Cartographers (GIs)
- Evaluations held on ATSAI's softcopy evaluation workstations
 - Controlled ambient lighting
 - Calibrated precision color monitors
- Display software permitted limited image manipulation:
 - Roam, 1X and 2X zoom
 - No capability to visually enhance imagery



Analysis & Reporting

- Results of evaluations undergo statistical analysis to determine:
 - Outliers (evaluators, specific images or questions)
 - Interactions between variables such as climate, GSD, etc
- Report describes procedure and incorporates analysis to present results
- Peer reviewed within ATSAI and by management chain before release to the customer



Summary

- CCAP evaluation of Ikonos not yet completed
- Once complete, results will be reported to CIP
- Methodology used in Ikonos evaluation provides a framework for evaluations of other high-resolution commercial sensors:
 - Investigate comparable products
 - Acquire same scene locations and climate parameters



CCAP POCs

- CCAP Team:
 - Braxton Baldrige
703-262-4345
baldrdb@nima.mil
 - Zedric Teague
703-262-4215
teaguez@nima.mil
- Commercial Imagery Program:
301-227-3520